



BLMA Models
16623 Pear Blossom Ct.
Whittier, California 90603
Phone: (562) 712-7085
sales@blmamodels.com

Installation Instructions

Early Locomotive Cut Lever

1. Shave the molded on cut lever from your model with a sharp hobby knife.
2. Locate the etched fret of mounting pins and remove them by either cutting them out or bending them front to back.
3. Locate the drill template holes on the etched fret frame and tape the entire frame to the front (pilot) of your locomotive so that the holes are at the proper height (see prototype photos to the right).
4. With your holes drilled, locate one of the wire cut levers and loop four mounting pins on either side. We suggest using a combination of the long and short mounting pins so you aren't inserting them all at once (you will do long first and then short).
5. Add a dab of glue using a tooth pick into each of the four holes you drilled and insert the mounting pins and cut lever one by one.
6. Paint as desired.