



BLMA Models
16623 Pear Blossom Ct.
Whittier, California 90603
Phone: (562) 712-7085
sales@blmamodels.com

Installation Instructions

EMD Spartan Cab Doors

1. Remove door from etched frame with a sharp hobby knife.
2. If you are going to "prop" the door open on one of your models, we suggest painting it at this time.
3. To remove a molded - on door from a plastic shell, we suggest drilling a series of small holes, connecting them with a sharp blade, then cleaning out the excess with a combination of blades and files.
4. Notice that there is a hole directly above the window to mount a windshield wiper (BLMA #96).
5. We suggest using clear styrene for the window though Microscale's Krystal Klear would work as well.