



BLMA Models
16623 Pear Blossom Ct.
Whittier, California 90603
Phone: (562) 712-7085
sales@blmamodels.com

Installation Instructions

Trainline Air Hoses

1. Remove the moldings from spur with a sharp hobby knife.
2. The mount on these air hoses is .016", so a drill bit around that diameter should work fine.
3. Drill a single hole in the proper place (view prototype photos) and mount in the hole with glue.
4. We suggest painting the angle cock (top) and hose coupler silver (bottom) and the actual "hose" part a flat black (to simulate rubber).