



BLMA Models
16623 Pear Blossom Ct.
Whittier, California 90603
Phone: (562) 712-7085
sales@blmamodels.com

Installation Instructions

Cab Air Conditioner Kit - Vapor Style

1. Remove the three pieces of the air conditioner from the etched frame using a sharp hobby knife.
2. Notice that the center piece (with five holes in it) will fold into a box, utilizing the fold lines on it's underside. Using the method of your choice, fold the sides of this part perpendicular to the center to create a bottomless box.
3. Using a small amount of glue, mount your box from step two onto the bottom plate (rectangle surrounded by rivet detail).
4. To complete, simply glue the top etching (with grill detail) in place, mount, and paint to the desired color (consult reference photos where needed).