



BLMA Models
16623 Pear Blossom Ct.
Whittier, California 90603
Phone: (562) 712-7085
sales@blmamodels.com

Installation Instructions

Angled Cab Sunshades

1. Drill the mounting holes with a #80 drill bit. (Note: We have provided you with a drill jig toward the side of the etching.)
2. Once your holes are drilled, insert the Sunshade so that the half-etched portion is up. (Note: we half-etched the shade so paint will adhere nicely).
3. Once that is in place, mount the track (long, thin piece) directly under the Sunshade and secure in place with glue.